

Flight mode

When boarding an airplane or entering an area in which it is prohibited to radiate radio signals, e.g. during flight, flight mode must be activated. The hearing aid will still be working. It is only necessary to activate flight mode on one hearing aid.


miniRITE



- **To activate and deactivate** •
Press the push button for at least 7 seconds. A jingle confirms your action.

Opening and closing the battery drawer will also deactivate flight mode. See chapter "Quick reset".

miniRITE-T



Press either end of the button